




SWORDTAIL

CELLO SYSTEM

Each pre-amp has been voiced for the acoustic properties of a Cello.

Pick-Up Input (RCA) 




Fine Tuners 

Tone Control
(Outer ring) 

Volume 

Output
Jack 



BATTERY INSTRUCTIONS



Uses (2) AA Batteries.

To prolong battery life, unplug 1/4" cable from output jack when not in use.